

How To Guide:

FLAT MATTE

STEPS:

Flat Matte completes your CeCe Caldwell's Paints project with a no-sheen finish.

1. Stir or shake to mix product.
2. Flat Matte can be brushed on or sprayed on from a spray bottle.
3. Apply first coat.
4. Remove any pooling of product.
5. Apply second coat while first coat is still damp.
6. Remove excess or pooled product.
7. Excess product can turn milky if left to dry.
8. Allow 3-4 hours for product to thoroughly dry.
9. This product should only be used on absorbent wood substrates. Do not dilute or thin Flat Matte. On a wood surface that has been prepared for Stain + Finish, you may apply 2-3 coats of Flat Matte. It will aid in making your Stain + Finish surface more water resistant.

PRO TIPS:

Protect your finished surface from strong acids, oxidizers and grease.

Store and use between 55°-95° degrees F.