

How To Guide: METALLIC WAX

STEPS:

1. Metallic Wax should be applied to a clean, dry surface that is free of dirt, oil and grease.
2. CeCe Caldwell's Metallic Wax can be directly applied with your finger, sponge, stiff brush, or lint-free cloth.
3. Allow Metallic Wax to dry.
4. Drying time varies depending on materials, thickness of application and substrate.
5. Generally, it is dry to the touch in approximately 30 – 60 minutes.
6. Lightly buffing, after 12 hours of drying, will result in a gilded-look finish.

PRO TIPS:

Creating custom colors of CeCe Caldwell's Metallic Wax is as easy as mixing two or more colors. You can use to match and touch up existing color schemes or to blend a one-of-a-kind color.

Rubbing wax immediately after application with a dry cloth or slightly moist cloth with Clear Wax will remove CeCe Caldwell's Metallic Wax from the relief details and will highlight the depressed details. Conversely, lightly brushing an application of CeCe Caldwell's Metallic Wax over the raised tops will highlight the raised relief details.

Use of CeCe Caldwell's Metallic Wax with a stencil creates an elegant effect. Paint substrate with CeCe Caldwell's Paints. Then, with stencil and stenciling brush, apply one or more layer(s) of CeCe Caldwell's Metallic Wax onto the paint in the void of the stencil.

Protect your finished surface from strong acids, oxidizers and grease.

Store and use between 55° - 95° degrees F.