

How To Guide: STAIN + FINISH

STEPS:

1. Prepare your wooden piece for Stain + Finish.
2. Comprehensive instructions may be found here. If you are working with a type of wood that does not take stain well, consider using a wood conditioner. [This article](#) should help you decide if you should pre-condition.
3. Once you are ready to apply Stain + Finish, stir the contents of the container well.
4. Make sure you incorporate all of the solids that may have settled.
5. Do not shake container.
6. Using a good quality synthetic bristle brush or staining pad, apply Stain + Finish. Always apply with the direction of the wood grain.
7. Allow surface to dry approximately 30 minutes.
8. Lightly sand with steel wool or high grit sandpaper before applying additional coats. Always sand in the direction of the grain.
9. Continue applying up to 6 coats of Stain + Finish until you reach the desired shade.
10. Lightly sand between each coat.
11. If you apply less than 3 coats of Stain + Finish, a coat of Endurance Finish or Waxing Cream is suggested.