

How To Guide: GENERAL WAXING TIPS

PRO TIPS:

Apply all wax products sparingly. Use a “less is more” approach. The number one mistake made with any wax is over-applying it. With all waxes, you will achieve best results if you apply 2 light coats versus 1 heavy coat.

The best way to learn the proper technique of wax application is to remove a small portion of wax from the can and spread it onto a piece of cardboard or a paper plate. Pick up some wax with your brush or cloth and wipe the brush/cloth off on another area of the cardboard/paper plate to ensure it is evenly coated and not overloaded in a single spot on the brush/cloth. Apply to project, returning to the cardboard/paper plate to pick up additional wax. Often, you can pick up from the area on the cardboard/paper plate where you wiped off your brush/cloth. For continued shine and protection, re-apply the wax every 6-12 months under normal conditions.

WAXING CREAM

STEPS:

1. Apply Waxing Cream with a flat-bottom (not pointed) brush or with a piece of lint-free cheesecloth.
2. Apply a VERY thin coat of Waxing Cream, similar to the amount that you would have on a paintbrush if you were dry brushing with paint.
3. SPARINGLY is the key word.
4. Buff it with a clean lint-free cloth/rag. Most find this thin, first coat is ALL that is needed. It shines up quickly with a light buffing. You can immediately add a second coat if needed/desired.
5. Waxing cream takes approximately 30 days to fully cure.

6. For continued shine and protection, re-apply the Waxing Cream every 6-12 months under normal conditions.

PRO TIPS:

Protect your finished surface from strong acids, oxidizers and grease.

Store and use between 55°-95° degrees F.

ADVANTAGES:

Uses less wax to achieve better results (more economical).

Less effort (buffing) needed to get higher shine.

Waxing Cream provides deeper penetration of wax into the paint.

CLEAR WAX

STEPS:

1. Clear Wax should be applied in a thin, even coat with a flat-bottom brush or lint-free cloth.
2. Apply sparingly. Always use less wax than you think is needed. It is best to apply several thin layers than one heavy layer.
3. Wipe away excess. The surface should then be thoroughly buffed with a dry cloth, piece of brown kraft paper, or finishing pad after 2-4 hours.
4. For an even harder finish, the wax can be rebuffed 2-4 days after the initial buffing. This product requires several weeks to fully cure.
5. Freshly waxed surfaces should be kept free of moisture and heavy use for about a week. For continued shine and protection, re-apply the Clear Wax every 6-12 months under normal conditions.

PRO TIPS:

Protect your finished surface from strong acids, oxidizers and grease.

Store and use between 55-95 degrees F.